



Pro *Nature*

Rock

Truly Eco-Friendly
Wall Paints,
Cleaning Products
Wood & Stone Finishes.

Locally Produced
Natural & Sustainable
Truly Eco-Friendly!



Tel: 0860 105 299
www.pronature.co.za

Blend of plant oils and gum rosin for the impregnation and protection of stone and masonry.

INGREDIENTS

Linseed oil, gum rosin, and plant oils, essential oils, lead-free driers.

Note: Natural products are not odour and emission free. Consider possible allergies!

TVOC (total volatile organic content) = 547.73 g/litre

AREA OF USE

For the impregnation and sealing of terra cotta tiles, slate, masonry, travertine, concrete, face brick and clay and lime plaster and many other mineral substrates.

COVERAGE

Approximately 12 – 16 m²/litre; on highly absorbent surfaces substantially lower.

SURFACE PREPARATION

All surfaces must be clean, dry and free of loose particles. Care must also be taken to provide a neutral surface. Therefore, it is recommended to pre-treat surfaces with an acid wash (follow supplier instructions!). Rinse acid washed surfaces well and leave to dry.

APPLICATION

Stir material well before application.

ProNature Rock is applied liberally using a brush or short bristle paint roller. In order to avoid glossy spots, it is important to remove any excess that has not been absorbed after about 15 min using a lint-free cloth or suitable machinery. Leave to dry for 12 hrs.

Then apply second coat of **ProNature Rock**. Remove any excess that has not been absorbed after about 15 min and leave to dry. Normally two coats of **ProNature Rock** are sufficient. Very absorbent surfaces like terra cotta tiles will need further applications. Cotta tiles should be treated until complete saturation is achieved. Allow drying times of 12 hrs in-between coatings.

❗ Cold weather and high humidity will retard the drying!!!

CLEANING and CARE

For the first two weeks' floors should not be cleaned wet but only swept. There after floors are cleaned with a neutral soap solution and wiped with a damp cloth only. **ProNature Rock** is spot repairable and should small damages from wear or scratching occur just clean the area thoroughly and sand concerned area lightly with steel wool or fine scouring pad. Remove dust and apply a thin layer of **ProNature Rock** with a soft cloth, remove any excess that has not been absorbed after about 15 min. Leave to dry for approx. 12 hrs. The treated area should not be walked on for 48 hours.

GENERAL INFORMATION

ProNature Rock is ready to use and needs not be diluted. Depending on surface type a thinning down of the first coat with about 10 % of **ProNature Plant Turpentine** may be required. Clean brushes and equipment with **ProNature Plant Turpentine**.

SAFETY PRECAUTIONS

Caution: Product is inflammable! Soaked, used cloths may spontaneously combust, and should be spread open, or kept safely in a tightly sealed tin after use.

PACKAGE SIZES

1 l, 5 l and 25 l

STORAGE STABILITY

A minimum of 6 months in unopened containers when stored in a cool and dry place.

General

The above information given is intended as a guideline only. Since this product is used outside of our control, EnviroTouch CC cannot be held liable for any loss or damage whatsoever relating to the application or surface it is applied to. We reserve the right to change specifications at any time and without prior notice.

Last revised: 4/2016